



DISxRSE

FIRMWARE and WEBSERVER Upgrade Procedures

Mar. '20

1 FIRMWARE UPGRADE


To upgrade the DISxRSE firmware, follow this procedure:

| Step | Action |
|------|--------------------------------------|
| 1 | Execute the BootLoaderApp.exe |

Tick the **Enable** box in the **Ethernet** section.

Enter the DISxRSE IP address and click the **Connect** button.

Note: the default IP address is **192.168.1.201**



| | |
|---|---|
| 3 | Click the Load Hex File button and select the file Firmware.hex |
|---|---|


Click the **Erase-Program-Verify** button to start the upgrade: it takes less than 30 seconds.

| | |
|---|--|
| 4 |  When uploading firmware, do not interrupt the application by closing the window. |
|---|--|

| | |
|---|---|
| 5 | Click the Run Application button, then click the Disconnect button. |
|---|---|

2 WEB-SERVER UPGRADE

To update the DISxRSE WebServer, follow this procedure:

| Step | Action |
|------|--|
| 1 | <p>Access the DISxRSE WebServer by typing the Url http://<display IP address>/mpfsupload</p>  <p>Example: http://192.168.1.201/mpfsupload</p> |
| 2 | Click the Choose File button and select the file WebServer.bin |
| 3 | <p>Click the Upload button to starts the process: <u>it usually takes less than one minute.</u></p> <p>⚠ When upgrade process is running, do not interrupt the web browser by closing the window, or loading a new page. If the browser is interrupted, it could corrupt the firmware.</p> <p>The following message will be shown to confirm that the firmware has been updated correctly.</p> |
| 4 |  |
| 5 | Click on Site main page link to finish the procedure. |